

# **How to Apply the VL-ID UNIT with SuperGlue**

## **Recommended Products:**

1. Isopropyl alcohol or Patch Rubber Company's Tire Cleaner Fluid
2. 60 grit sandpaper
3. Scraper
4. Clear Packaging Tape
5. Plastic knife or cotton swab
6. Dap Rapid Fuse SuperGlue

## **Installation Instructions:**

1. ID UNIT should be mounted next to or near the DOT #. ID UNIT should touch "GG Ring" or be as close to the rim as possible.
2. If acceptable, rough surface with sandpaper
3. Spray area with Tire Cleaner Fluid (alcohol) and allow to penetrate. Scrape or wipe Clean. Repeat until area is clean.
4. Place ID UNIT on 6" piece of packaging tape face down, so barcode is on "sticky side". Remove backing from ID UNIT.
5. Place a several drops of DAP SuperGlue on ID UNIT and spread with plastic knife. The "teeth" on the knife should evenly spread the SuperGlue across the ID UNIT.
6. Place ID UNIT and hold with pressure for 1 minute. Gently remove packaging tape.
7. ID UNIT must sit untouched for at least 30 minutes for SuperGlue to cure.

**If You Have Any Questions, Please Call us**

TIRE-TRACK LLC

5 Trowbridge Drive, Bethel, CT 06801

(475) 329-5158